

Installation of Commercial Pour In Place Eco-Rubber

Instructions to prepare and clean the cement mixer:

1. Prior to mixing, wipe the mixer and paddles with diesel fuel.
2. During breaks, or at the end of the day, wipe the mixer by hand and get all the rubber out.
3. At the end of the project, use 1 gallon of acetone and 5 gallons of 57 stone (3/4" gravel), put into the mixer, fill mixer tank with gas, run until gas is empty.

Production rates:

1. Set up the mixer in the middle of the area near the application.
2. Get a "Georgia Buggy" motorized wheel barrow, line with plastic tarp, so you can move the rubber to the locations quickly.
3. A crew of 3 could do 1200 to 1500 sf per day.
4. Crews must wear long gloves. Be careful when crews have glue on their hands, don't touch controls on Georgia Buggy, or that needs to be cleaned with acetone, also - best to just have a dedicated Georgia Buggy operator not handling rubber.